

650 Jernee Mill Road Sayreville, New Jersey Phone (732) 254-1901 Fax (732) 254-4423

Category: Makeup – Lip

Ingredient	INCI	Supplier	W/W%
Phase A (Oil)			
Dermol DGDIS	Polyglyceryl 2-Diisosterate	Alzo International	9
Polyderm PPI-CO	Castor Oil/IPDI Copolymer	Alzo International	5
Performalene 400	Polyethylene	New Phase Technologies	6
Performacol 350	C20-40 Alcohols	New Phase Technologies	8
SP89	Microcrystalline Wax	Strahl and Pitsch	2
SP1026	Ozokerite Wax	Strahl and Pitsch	2
NuLastic Slip D99 9	Isononyl Isononanoate (and) PEG-10 Dimethicone/Vinyl Dimethicne Crosspolymer	Alzo International	35
Phase B (Aqueous)			
Water	Water		6.5
Glycerin	Glycerin	Alzo	10
Allantoin	Allantoin	DSM	0.5
Tween 60	Polysorbate 60	Croda	3
Dermol CG	Caprylyl Glycol	Alzo International	0.5
Phenoxetol	Phenoxyethanol	Clariant	0.5
Phase C (Pigment)			
Unipure Red LC 381 Aq	Iron Oxide	Sensient	4
Unipure White 981 Aq	Iron Oxide	Sensient	3
Unipure Yellow 182 Aq	Iron Oxide	Sensient	1
Cloissonne Sparkle Gold	Mica (and) Titanium Dioxide (and) Iron Oxides	BASF	1.67
Flamenco Twilight Red 430ZB	Mica (and) Titanium Dioxide (and) Iron Oxides	BASF	1
Kobo KTZ Classic White	Mica (and) Titanium Dioxide	Kobo	1.33
Total			100.00

DR1-39: NuLastic Slip Skin Conditioning Lipstick with Allantoin

Manufacturing Procedure:

- 1) Melt Phase A without Nulastic and mix
- 2) Add Nulastic to Phase A and mix until homogenous
- 3) Add Phase B into Phase A and mix well Mix using Silverson Homogenizer
- 4) Mix in Phase C until color is completely dispersed. Continue Mixing using Homogenizer
- 5) Once at a constant temperature of 85°C pour into lipstick mold

Alzo Ingredient Benefits:

Dermol DGDIS – Good pigment-wetting ester that imparts gloss, and substantivity to the lips.

Nulastic Slip D99-9 – Silicone elastomer with PEG crosslinking that allows incorporation of water & water compatible ingredients, such as glycerin.

Polyderm PPI-CO – Polymerized Castor Oil, which provides substantivity and shine to lip products, and improves wearability and film forming.

All information contained herein is intended primarily to demonstrate the utility of **ALZO** products. Suggestions for uses or applications are only opinions. The user is responsible for determining the suitability of these products for their own particular purpose. We assume no liability in the presentation of this data, nor should this information be constructed as granting license to practice any methods or compositions of matter covered by U.S. or foreign patents.